



SQUEAKY FOAM

POGO JUMPER FOR

KIDS - PLAY22

Original



INSTRUCTIONS AND CAUTIONS TO USE

- ✓ No assembly required
- ✓ Always wear appropriate safety gear, including a helmet, knee pads, and elbow pads.
- ✓ Ensure that the area where you will be jumping is clear of any obstacles or hazards
- ✓ Place the pogo jumper on a flat surface and ensure that it is stable.
- ✓ Step onto the foam base with one foot and then the other, gripping the soft foam handle with both hands.
- ✓ Use your legs to push off the ground and start jumping
- ✓ Keep your balance by focusing on a point in front of you and using your arms for stability.
- ✓ To stop jumping, simply slow down your bouncing and come to a stop
- ✓ Do not use the Pogo Jumper on uneven or slippery surfaces.
- ✓ Do not attempt to perform tricks or stunts on the pogo jumper.
- ✓ Do not use the pogo jumper near stairs, slopes, or drop-offs.
- ✓ Always supervise children while they are using the pogo jumper to ensure their safety.

This foam pogo jumper is the perfect toy for kids and adults alike! This fun and safe jumping stick will provide hours of active entertainment for your family. The long-lasting foam base and comfortable soft foam handle make it perfect for indoor and outdoor play. Not only is the toy fun, but it also encourages an active lifestyle. It's a great tool for balance training and coordination learning, making it a perfect gift for boys and girls of all ages.

The built-in squeaker adds an extra layer of excitement, making each jump even more fun than the last. Safety is a top priority with the toy. It's 100% safe for ages 3 and up, and can hold up to 250 lbs, so both kids and adults can enjoy it. Additionally, it meets all CPSC safety standards, giving you peace of mind while your child is playing. Give the gift of active fun with the Foam Pogo Jumper - satisfaction is guaranteed.

The Play22 Customer Service Number
888-279-2783

