



24 KEYS COLORFUL KEYBOARD PLAYMAT *Play22 Original*

Get ready to unleash your little one's inner musician! This gigantic **electronic keyboard playmat** boasts 24 touch-sensitive keys and 8 different musical instruments including piano, saxophone, violin, and more. With four different play modes - record, playback, demo, and play - and adjustable volume, this keyboard mat offers endless hours of musical fun and creativity. Made from super-strong vinyl, it's built to last and meets all US safety requirements.

INSTRUCTIONS AND CAUTIONS TO USE



The Play22 Customer Service Number
888-279-2783

- ✓ No assembly required
- ✓ Unroll the keyboard mat on a flat surface.
- ✓ Install 4 AA batteries in the battery compartment located on the side of the mat.
- ✓ Turn on the power button located on the top left corner of the mat.
- ✓ Select your desired instrument by pressing the corresponding button.
- ✓ Adjust the volume by turning the volume knob located on the top right corner of the mat.
- ✓ Start playing the piano by tapping on the keys with your feet or hands.
- ✓ Use the record, playback, and demo buttons to create and listen to your own music.
- ✓ Recommended for children ages 3 and up and should be used under adult supervision.
- ✓ Do not place heavy objects on the mat or expose it to extreme temperatures.
- ✓ Do not use the mat near water or other liquids.
- ✓ Always turn off the power when not in use to save battery life and prevent damage to the product.

